


1 Trig 6Cyl 1Coil 5V Hall


Harness Required: E03 Ver 1.0 & E02 Ver 1.0

Last Changed: 17/07/2008

Drawing Ver: 1.0





Led's Functions
Yellow - Power
Green - RPM Pulse




Connect supply wires at the battery terminal if
the relay coil is not connected to ground.

Yellow GP Output 1
Green Not Connected



Max Load = 500mA to Ground
Connect to Relay











Red 2.5mm2
at the battery terminal if
the relay coil is not connected to ground.



R2+



Firing Order Example
A B C D E F
Blue = A+D
Green = B+E
Yellow = C+F
(See Injector Wiring in EMU User Manual)



Balance Solenoid