


6Cyl Straight Split Seq High Imp Injector Add-on

Last Changed: 13/11/2017

Harness Required: MEX01-2 + IV6X01-2




Software Settings

Injection Type

Split Sequential

Micro Fueling Type


Off



Step 1

Write your firing order from left to right in the blocks above marked with an alphabetical letter. Then write the corresponding number on the corresponding injector with the same alphabetical letter in the drawing below.


Note: The order of the injectors will differ on the placing on the engine, as long as it is connected to the same colour wire as this illustration. Two coils are connected to one wire colour from the MEX01-2 as they are pulsed together. Connect them as such.



Step 2

Write the corresponding colour of each cylinder next to your injector number on the lines marked X on the drawing. This will ensure that the sequence of injection is correct.

Step 3



Solder joints and cover it with shrink sleeve

IS6X01-2 = Harness Part numbers
MEX01-2

Neg = Harness Tag Name