

## TITAN Injector Wiring 6Cyl


Last Changed: 15/06/2010 Drawing Ver: 1.0







**NB!** Connect the Positive to the Negative between injectors

Firing Order 123456







**Note!** Your firing order and piston numbers may differ from the examples. Determine which pistons move up and down together and wire them together. See also the manual for how to determine from the firing order which injectors must be grouped together.