Signal Conversion

<u>File Name:</u> Signal Conversion <u>Last Changed:</u> 02/04/2012

Tap into existing magnetic trigger | Magnetic Crank | Signal | To Original ECU | | To Spitronics ECU |

Note! If their Ref voltage is 12V, You may swop the polarity on the cap.

Unless other value spesified





