

Timing - EMU


Harness Required: E05 Ver 1.0 (Hall) or E06 Ver 1.0 (Magnetic) & E07 Ver 1.0

Last Changed: 04/10/2007

Drawing Ver: 1.0

Ign+ Ignition Power
 Earth
Terminal Connections with the same name are tied together

Led's Functions
 Yellow - Power
 Green - RPM Pulse



Optic / Hall Pickup

Harness	Description
1. Red	Sensors +
2. Blue	Signal
3. Screen	Sensors -

Magnetic Pickup

Harness	Description
1. Red	Sensors +
2. Blue	Sensors -
3. Screen	Not Connect

Connector Pin View

7	8	9	10	11	12
1	2	3	4	5	6

- 1. 3. Blue - Map Sensor
- 2. 4. -
- 3. 5. Blue - Hall Input 1
- 4. 6. -
- 5. 7. -
- 6. 8. Blue - +5V Output
- 7. 9. Red - +12V Ign Input
- 8. 10. -
- 9. 11. (Red) - Magnetic Input 1+
- 10. 12. -

Connector Pin View

6	7	8	9	10
1	2	3	4	5

- 1. 4. Blue - Fuel Relay GP Output 1
- 2. 5. Red - Coil+
- 3. 6. Brown - RPM Output
- 4. 7. -
- 5. 8. -
- 6. 9. Green - RPM Output
- 7. 10. -