

E26 V8 Chev 4Coil 4Inj

Firing Order 18436572


Last Changed: 13/05/2011

Drawing Ver: 2.0


Ign+
T Ignition Power
Earth

Terminal Connections with the same name are tied together

Led's Functions
Yellow - Power
Green - RPM Pulse



Connector Pinouts



Harness Pin View

- 1. Blue - Coil 5&8
- 2. Green - Coil 2&3
- 3. Yellow - Inj RF
- 4. Blue - Fuel Relay
- 5. Red - Inj RR
- 6. Red - Coil 1&6
- 7. Yellow - Coil 4&7
- 8. Green - Inj LF
- 9. Green - RPM Output
- 10. Blue - Inj LR

