## 2Cyl COP Int Drv

<u>Last Changed:</u> 13/11/2017 Harness Required: MEX01-2

Harness Pin View

1. Red/White - Coil Drv 1

6. Red/Yellow - Coil Drv 2

Connector Pinouts

2. Red/Orange -3. Red/Blue -4. Blue/Red -5. Red -


7. Red/Green -8. Red/Black -

10. Red



Write your firing order from left to right in the blocks above marked with an alphabetical letter. Then write the corresponding number on the corresponding coil with the same alphabetical letter in the drawing below. Now connect your coil number to the corresponding colour wire.

Note: The order of the coils will differ on their placing on the engine, as long as it is connected to the same colour wire as this illustration. Two spark plugs in two pairs are driven by one coil. Make sure the HT leads are paired correctly as the alphabetical letters indicates.



Software Settings

Coil	Com	oinati	ion
------	-----	--------	-----

Wasted Spark Coil Pack