

# **OC1 P1 Harness**

## **Products that can use this harness**

- Orion Coil Drivers

## **History**

- This Level 1 harness is connector and pins only and is used with all of the Orion Coil drivers. It contains only the inputs from the ECU. The module itself does not need power like the Mercury Coil Drivers. You will connect your Positive Coil Outputs from the ECU to this connector via the pins that were supplied.

## **Design Points to take Notice of.**

- The Inputs does not have wires but comes with the pins so that the installer can add them to the Mercury3 or Orion2 Output wires. This will eliminate the need for a wire-to-wire connection and leave the harness neater. If you have an issue soldering and inserting the pins ask the dealer to do it for you before shipping.

## **Wire Names and connections on this harness:**

6x Coil Inputs from Mercury3 or Orion2 (Striped Red)(Not installed)

See the design drawing for thickness and lengths of wires. See the connection drawings in the specific product manual on how to connect the harness to each item it was designed for.

***NB!*** Wires that are not connected must be isolated to prevent shorts or interference.