

Venus3 Quick Link Reference

Open the Index on the left side of the PDF files

Accelerator Pump	Manual	
Air Temp	Manual	Drawings
Altitude	Manual	Drawings
Android Software	Manual	Software Zip
Anti-Lag	Manual	Folder
Battery Volts	Manual	Drawings
Calibrate Spark Timing	Manual	
Cloning	Manual	
Coils	Manual	Drawings Folder
Compiling an ECU	Excell	
Crank & Cam	Manual	Drawings
Venus3 Drawings Manual	Manual	
ECU Home Screen	Manual	
Engine Limiters	Manual	
Engine Settings	Manual	
Firmware Class Features	Folder	
Flat Shift	Manual	Drawings
Fuel Econno Tuning	Manual	
Fuel Pump	Manual	Drawings
Fuel Settings	Manual	
GP Outputs	Manual	Drawings Folder
GP Priority Layouts	Folder	
Hardware Classes	Folder	
Hyperspace Ver 3.6	Manual	Software Zip
Idle	Manual	Drawings Folder
Injectors	Manual	Drawings Folder
Jumpers		Drawings
Lambda Sensor	Manual	Drawings
Launch Control	Manual	Drawings
MAP Lock Feature	Manual	
MAP Sensor	Manual	Drawings
Matrix Map Tuning	Manual	
Matrix TPS Tuning	Manual	
Memory Handling	Manual	
Pin Layouts	Folder	
Relay Power		Drawings
Settings Before Tuning	Manual	
Starting First Time	Manual	
Timing Settings	Manual	
TPS Sensor	Manual	Drawings
Tuning Basics	Manual	
Tuning Map Operation	Manual	
Tuning POT Sensor	Manual	Drawings
Transmission Tuning	Manual	
Water Temp	Manual	Drawings