


Lexus Racing Gearbox Connection

Harness Required: E21 or E27

Last Changed: 03/02/2012



Put GP2 on "RPM"
 "Min" Gear down RPM value
 "Max" Gear up RPM value

NC - Not Connected
 Ign+ Ignition Power
 Earth

Terminal Connections with the same name are tied together

Led's Functions
 Yellow - Power
 Green - Diagnostic

