

Mercury2 ECU Jumper Settings

Last Changed: 16/01/2019



Jumper Settings

Crank Pull-up

J1 & J2



TDC Pull-up

J1 & J2



Jumper must be on for Hall or Optic sensors
and off for Magnetic reductors